

PROBLEM	CAUSE	SOLUTION
Although the lever release button and brush rotation levers are pressed at the same time, the machine does not start.	The appliance is unplugged.	Plug the appliance in.
The pad holder does not rotate.	The brush/pad holder rotation lever is not pressed. Presence of foreign bodies.	Press the lever. Remove any foreign bodies stuck in the appliance.
No water is released	The tank is empty. Water supply lever not pressed.	Fill the tank. Press the lever.
Polishing liquid is not released.	The tank is empty. Button not pressed.	Fill the tank. Press the button.
Insufficient floor cleaning	Pad or chemical product not suitable. Pad worn.	Use a pad or chemical product that is appropriate to the type of floor to be polished. Replace the pad.
The machine operates erratically or vibrates heavily.	Check that the pad is perfectly centred in the pad holder. Pad not suited to floor type.	Replace the pad, centring it correctly in the pad holder. Use a pad suited to the floor surface.
The machine turns off unexpectedly during operation.	Motor thermal protection activation.	Restore the reset button until it "Clicks" and make sure to work in the correct range.